Workshop UAustral: Práctico 1

Ensamble de genomas, anotación y búsqueda de homólogos





Researcherid J-6429-2012


















@JM_bioinfo



History and Context



iPlant 2008

Empowering a
New Plant Biology












iPlant 2013

Cyberinfrastructure for Life Science



A "new type of organization" that is "community-driven" uniting "biologists, computer and information scientists and experts from other disciplines working in an integrated team" to provide "computational and cyberinfrastructure capabilities and expertise that are capable of handling large and heterogeneous plant biology data sets"



CyVerse 2016


Transforming Science
Through Data-Driven
Discovery

~ \$100m direct NSF investment over 10 years

Currently working to sustain its successes beyond 2018







Tipos de archivos que usaremos

- FASTA
- FASTQ

```
cat SRR1811524_1M.fasta | head -n 12
```

```
>SRR1811524.2 HWI-ST615:645:H7P8JADXX:1:1101:1414:2351/1 CTTAGCTTGTCGAAACAACATCCAAGAGTTCATGCTTAACCAACTCGGAAT >SRR1811524.3 HWI-ST615:645:H7P8JADXX:1:1101:1416:2377/1 CCGACTTGTTCTGCGTATCTAGACTAACTCTGGTTTCCCTCTTAGACAAAG >SRR1811524.4 HWI-ST615:645:H7P8JADXX:1:1101:1479:2437/1 CAAACACTTTCCAGGATACCACTCAATCTCCGTCCCGAGGGCCTTCTCAAG
```

cat \$RR1811524_1M.qual | head -n 12

cat SRR1811524_1M.**fasta** | head -n 12

```
>SRR1811524.2 HWI-ST615:645:H7P8JADXX:1:1101:1414:2351/1 CTTAGCTTGTCGAAACACATCCAAGAGTTCATGCTTAACCAACTCGGAAT
```

identificador → >SRR1811524.3 HWI-ST615:645:H7P8JADXX:1:1101:1416:2377/1

secuencia → CCGACTTGTTCTGCGTATCTAGACTAACTCTGGTTTCCCTCTTAGACAAAG

>SRR1811524.4 HWI-ST615:645:H7P8JADXX:1:1101:1479:2437/1

cat \$RR1811524_1M.qual | head -n 12

```
identificador → >SRR1811524.3 HWI-ST615:645:H7P8JADXX:1:1101:1416:2377/1
```

(probability of error) = $10^{-(phred score)/10}$


Phred quality score	Probability that the base is called wrong	Accuracy of the base call
10	1 in 10	90%
20	1 in 100	99%
30	1 in 1,000	99.9%
40	1 in 10,000	99.99%
50	1 in 100,000	99.999%

cat \$\text{RR1811524_1M.qual} | head -n 12

Codificación

```
!"#$<mark>%</mark>&'()<mark>*</mark>+,-.<mark>/</mark>0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`abcdefghijklmnopqrstuvwxyz{|}~
0 1 2 3 ..
```

zcat SRR1811524_1M.fastq.gz | head -n 12



zcat SRR1811524_1M.fastq.gz | head -n 12

```
@SRR1811524.1 HWI-ST615:645:H7P8JADXX:1:1101:1015:2373/1
              NAACACTCAACTTGAACGCAATGAACCAGGCACCAAACCCATGGCACGTGT
identificador → @SRR1811524.2 HWI-ST615:645:H7P8JADXX:1:1101:1414:2351/1
  secuencia → CTTAGCTTGTCGAAACACCATCCAAGAGTTCATGCTTAACCAACTCGGAAT
  separador → +
    calidad → CCCFFFFFHFHHAHHIIIEHIGIIHIIIIGEEIIIIEGGIGHIEFHGIIG
```

Codificación de calidad

```
!"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^ `abcdefghijklmnopgrstuvwxyz{|}~
33
                                104
                                           126
0.....9......40
                0.2.....41
S - Sanger Phred+33, raw reads typically (0, 40)
X - Solexa Solexa+64, raw reads typically (-5, 40)
I - Illumina 1.3+ Phred+64, raw reads typically (0, 40)
J - Illumina 1.5+ Phred+64, raw reads typically (3, 41)
 with 0=unused, 1=unused, 2=Read Segment Quality Control Indicator (bold)
 (Note: See discussion above).
L - Illumina 1.8+ Phred+33, raw reads typically (0, 41)
```

E. coli

https://www.biostars.org/p/160377/

https://www.ebi.ac.uk/ena/data/view/ERX008638

ftp://ftp.sra.ebi.ac.uk/vol1/fastq/ERR022/ERR022075/

Microbacterium sp. CGR2

https://www.ncbi.nlm.nih.gov/genome/14190?genome assembly id=410147

ABRPI-Training


https://sepsis-omics.github.io/tutorials/modules/data-dna/



Cyberduck is a libre server and cloud storage browser for Mac and Windows with support for FTP, SFTP, WebDAV, Amazon S3, OpenStack Swift, Backblaze B2, Microsoft Azure & OneDrive, Google Drive and Dropbox.

https://wiki.cyverse.org/wiki/display/DS/Using+Cyberduck+for+Uploading+and+Downloading+to+the+Data+Store

https://cyberduck.io/download/



Los datos

El set de reads que usaremos son del genoma de una bacteria imaginaria de *Staphylococcus aureus* secuenciados en un instrumento Illumina. Corresponden a un subconjunto del genoma verdadero.

- •Los archivos que ensamblaremos son mutant_R1.fastq y mutant_R2.fastq.
- •(No es necesario un genoma de referencia).
- •Son paired-end.
- •Cada read tiene 150 pares de bases de largo.
- •El número de bases secuenciadas equivale a un 19x de cobertura de la cepa original lo cual es muy bajo pero útil para el ejemplo.

